

Saturn[®] In-Line Filters



*Revolutionary
in-line filters
simplify complex
maintenance
while effectively
trapping hot melt
adhesive
contaminants.*



Patented and Patent-Pending

The Saturn in-line filter assembly delivers easy access and simplifies filter maintenance. Used to reduce nozzle clogging and subsequent downtime, Saturn in-line filters can be easily and efficiently replaced as part of routine, scheduled maintenance.

Easy Replacement

The in-line filter assembly can be installed in straight, 45° and 90° configurations to permit filter accessibility. The inside-out disposable filter is replaced without having to disconnect the hose from the gun. The disposable filter is a threaded element that simply screws in or out for easy removal or installation on a pressure-purged hot melt adhesive system. Use of color-coded rings allows you to select the correct replacement filter every time.

Features

- **Filter replacement** without disconnecting the hose and gun.
- **Filter** can be positioned for easy accessibility.
- **Disposable** filter element.
- **Inside-out filter flow** traps contaminants for discard with the disposable filter cartridge.
- **Color-coded Saturn identification rings** for accurate filter replacement.

Saturn® In-Line Filters







Value packs save money, make replacement filters readily available, and display a convenient selector guide.

Specifications

Maximum Working Pressure 1500 psi

Maximum Recommended Adhesive Viscosity 10,000 cps

 SATURN® IN-LINE FILTERS	50 mesh	100 mesh	200 mesh
	.30 mm [.0117 in.]	.15 mm [.0059 in.]	.07 mm [.0029 in.]
	1007033	1007034	1007035
	1007233	1007234	1007235
	1007230	1007231	1007232
Disposable Filter Pack 2 Filters	1007036	1007037	1007038
Disposable Filter Pack 5 Filters (Value Pack)	1007372	1007373	1007374

For more information, talk with your Nordson representative or contact your Nordson regional office.

United States
 Duluth, Georgia
 Telephone: (800) 683-2314
 Toll-free Facsimile:
 (866) 667-3329

Canada
 Markham, Ontario
 Telephone: (800) 463-3200
 Facsimile: (905) 475-8821

Europe
 Luneburg, Germany
 Telephone: (49) 4131-894-0
 Facsimile: (49) 4131-894-149

Japan
 Tokyo, Japan
 Telephone: (81) 3-5762-2700
 Facsimile: (81) 3-5762-2701

**Asia/Australia/
 Latin America**
 Amherst, Ohio
 Telephone: (440) 985-4496
 Facsimile: (440) 985-1096

www.nordson.com



When you expect more.®