

# Series 141 Disposable Plastic Frother Mixer

The Series 141 Mixers are intended for urethane foam applications. The extended tube serves two purposes- (1) for reach and (2) to reduce the spiralling of material after the mix elements to allow for a more accurate dispense.

## Specification

- **Elements:** Acetal (161 & 141), Polypropylene (241)
- **Housing:** Nylon (141 & 241), Polypropylene (161)

## Accessories

- Manifold
- Retaining Nut



## Series 141 Frother Mixer

Part #	Mixing Elements	Flow Rate (PPM)	Element Diameter (inch/mm)	Housing Length (inch/cm)	Outside Diameter (inch/mm)
7701023 (161-224FFR)	24	15	0.50 / 12.70	13.2 / 33.53	0.67 / 17.02
7700679 (141-510FFR-40)	10	30	0.64 / 16.23	40.0 / 101.60	0.75 / 19.05
7700682 (141-520FFR)	20	30	0.64 / 16.23	24.0 / 60.96	0.75 / 19.05
7701712 (241-510FFR)	10	30	0.64 / 16.23	15.0 / 38.10	0.75 / 19.05
7700688 (141-612FFR)	12	60	0.79 / 20.07	25.0 / 63.50	0.93 / 23.62
7700690 (141-616FFR)	16	60	0.79 / 20.07	28.0 / 71.12	0.93 / 23.62
7700692 (141-616FFR-40)	16	60	0.79 / 20.07	40.0 / 101.60	0.93 / 23.62

# Series 141 Disposable Plastic Frother Mixer

For Nordson EFD sales and service in over 30 countries, contact Nordson EFD or go to [www.nordsonefd.com](http://www.nordsonefd.com)

East Providence, RI USA  
USA & Canada: 800.556.3484;  
+1.401.431.7000  
[info@nordsonefd.com](mailto:info@nordsonefd.com)

Dunstable, Bedfordshire, UK  
0800 585733; +44 (0) 1582 666334  
Ireland 00800 8272 9444  
[europe@nordsonefd.com](mailto:europe@nordsonefd.com)

China: +86 (21) 3866 9006  
[china@nordsonefd.com](mailto:china@nordsonefd.com)

Singapore: +65 6796 9522  
[sin-mal@nordsonefd.com](mailto:sin-mal@nordsonefd.com)

The Wave Design is a trademark of Nordson Corporation.  
©2010 Nordson Corporation v042610



**Nordson**  
EFD